



# Triple Evacuation

- Remove Schrader valves, connect hoses to the vacuum pump.
- Run the vacuum for ten minutes.
- Isolate gauges, disconnect the vacuum pump.
- Hook to the nitrogen tank, pressurize with dry nitrogen.
- Remove the hose, push out nitrogen and moisture.



- Reconnect gauges, run pump for ten more minutes.
- Remove opposite hose and run nitrogen through it.
- While running nitrogen through the system, disconnect both hoses, then put the Schrader valves back on.



- Run third evacuation for ten minutes.
- Hold for ten minutes.